



Easy to install



1

Thoroughly clean the subfloor with a broom or a vacuum cleaner, removing paint residuals or glue from earlier installations



2

Lay the first length of underlayment tightly against the wall across the full width of the room



3

Place the next layer of underlayment edge to edge, with no overlapping



4

Lay the vinyl floor in the same direction as the underlayment or at a 90 degree angle, follow LVT flooring manufacturer's recommendation. Picture shows vinyl floor and underlayment laid in same direction



5

Repeat process, following the instructions of the vinyl floor manufacturer until surface is covered